

Marquee Frame Installation Instructions

Please follow these steps for installation:

1. Place the Sidebars in a rectangle on a flat surface.
2. Place Corner Fittings in each corner.
3. For tents over 10 feet in length place the Mid-Leg Rafter between the Sidebars at 10-foot intervals with the letter "B" toward the Base.
4. Starting at one end of your Marquee, insert Rafters into End Top Fitting and End Corner Fittings; align the holes to snap buttons.
5. Continue to insert Side Bars to Mid-Leg Rafter Fittings and Top Bars to 4-Way Top Expansion Fitting to desired length.
6. Lastly, attach End Rafters to End Top Fitting and End Corner Fittings.

The Upper Structure is now complete.

7. Place cover loosely over frame while frame is still on the ground, attaching the Velcro™ strips on ends and middle.
8. Lift one side of the frame and attach two adjustable Legs (with Base Plates) in the lowest position in each corner. Repeat for the other side. Then attach (if applicable) the remaining Legs in each Mid-Leg/Rafter Fitting, also in the lowest position. (It is recommend two persons be available when lifting the frame to install the Legs.)
9. With the tent legs remaining at their lowest position, the cover should be attached with the straps and buckles. Start by securing one corner and then the opposite corner. Once the corners are secure, the straps should then be tightened. (Over tightening the straps can damage the cover.)
10. Raise the frame to desired leg height until snap buttons engage.
11. While this unit will stand on its own, it is imperative the tent be secured with ropes/ratchets and stakes or any other appropriate anchoring method. Anchoring is optional to our customers.