


## Bally Hardware & Skirt Installation

10' | 15'

### Part List

- 3 9'5" x 1 3/4" Bally Bars (10' wide tent) OR  
14'5" x 1 3/4" Bally Bars (15' wide tent)
- 2 Cast Bally Corner Fittings
- 2 Cast Bally End Fittings



1. Slide **Bally Corner Fittings** onto front tent legs and **Bally End Fittings** onto back tent legs from the bottom prior to attaching the tent leg base plates. (The gray leg rommet prevents install of Bally Fittings from the top.)
2. Bally skirts are 36" in height. Use this dimension as a reference for locating and securing each of the **Bally Fittings** on the tent legs. Bally Fittings have a thumb screw for easy adjustments.
3. Slide the each of the **Bally Bars** through the top pocket of each **Bally Skirt**.
4. Insert each **Bally Bar** with **Bally Skirt** into the respective **Bally Fittings** on 3 sides.
5. Secure sides of **Bally Skirts** to tent legs with ties.